



A blossom of
Verde Valley Rentals, Inc,

740 Airpark Way,
Cottonwood AZ

928-634-8531 x 1
800-293-7368

After Hours Emergency:
Leave a message on
either of the numbers above,
we will respond shortly.

Instructions

Coffee Makers

INCLUDES

Coffee Maker
Lid
Stem
Basket for Coffee

- Fill Coffee pot with cold water to desired amount.
- Add coffee to basket (see equivalents below).
- Plug coffee pot into standard outlet with nothing else plugged into it. Do not use extension cords.
- When coffee has finished brewing, remove basket, the pot will keep the coffee hot.

Cleaning

Rinse out the inside of the coffee pot & basket before returning.

NEVER IMMERSER THE COFFEE POT IN WATER.

Brewing Time

Approximately 45 min to brew 30-60 cup urns.

Approximately 1.5 hours to brew 90-100 cup urns.

Coffee Equivalents

Number of cups	Coffee Measure
30	3 cups
55	3.5 cups
100	6 cups

1 lb of coffee is equal to approximately 4 $\frac{3}{4}$ cups of ground coffee.