

Margarita Machine



Before You Begin:

- *The unit is very heavy, be sure it is on a level surface. Slight adjustments may be made with the legs.*
- *The unit must be plugged directly into a wall outlet (no extension cords please).*
- *If using machine outdoors, make sure unit is not in direct sun light. Caution: Unit may not freeze fully if placed outside during very hot weather.*
- *Make sure bowls are secure and in place before using. Failure to do so will cause drink mix to leak out of the bowl.*
- *The unit must have proper ventilation on all sides. DO NOT place it directly next to anything.*
- ***Please use only mix provided by Verve Events & Tents. If you use your own solution, Verve Events & Tents does not guarantee results, and you will be liable for damage caused to machine.***
- *If adding alcohol to the mix, be aware that this could prevent the mix from freezing completely.*

Operating Machine

Approximately 2 hours prior to use (3 hours with alcohol):

- *Pour Frusheez mix into bowl.*
- *Add 2 gallons of water to bowl – do not overfill. (if using alcohol please see tips below).*
- *Plug machine into wall outlet.*
- *All controls for the machine are behind the panel on the right side of the machine with separate controls for the right and left containers. NOTE: There is a 4 minute delay from the initial start once the compressor is on, green light illuminates.*
- *Turn on machine (the switch looks like a lightening rod).*
- *Turn on blades (the switch looks like a curved arrow).*
- *Turn on cooler (To make a frozen drink flip switch to the snow flake, to make a liquid drink flip switch to rain drop.)*
- *Make sure that you've turned on switches for both sides.*
- *Attach drip trays to front of unit. (There are little cutouts front the front of the machine where they hang.)*

Tips

- *If using alcohol:*
 - *For best results, add liquor to each glass and pour Frusheez mix into glass.*
 - *If you want to do all in one; start with 2 gallons of cold water and ½ gallon of chilled frusheez mix. Once the machine has achieved a complete slush consistency, add up to ½ gallon of cold alcohol. It will take approximately 1 additional hour to re-slush the mixture. Be aware that the alcohol mix will NOT achieve the same slush consistency as without alcohol.*
- *If serving more than 50 people, we suggest premixing the extra mix in a separate container and chilling it for refilling the machine. You can then be assured the ratio is correct and the mix will slush faster.*

Cleaning – DO NOT TAKE MACHINE APART.

- *Turn off cooler, wait for mix to melt.*
- *Once mix is all melted to liquid state, empty all mix out of bowl.*
- *Flush twice with water. (Water will freeze if cooler isn't turned off and this will damage the machine.)*

PLEASE - TURN OFF MACHINE IMMEDIATELY IF CLUNKING IS HEARD OR IF LARGE CHUNKS OF ICE ARE SEEN!

IF THE MACHINE IS NOT WORKING FOR YOU...Verve Events & Tents will be happy to send out a technician to assist you, however, if the above mentioned guidelines have not been met, a service charge of \$50 will be added to your rental.