



A blossom of
Verde Valley Rentals, Inc,

740 Airpark Way,
Cottonwood AZ

928-634-8531 x 1
800-293-7368

After Hours Emergency:
Leave a message on
either of the numbers above,
we will respond shortly.

Instructions

Popcorn Machine

NOTE: Pop one bag at a time to avoid burning kernels.
Do not cover air vent holes . motor air intake & exhaust holes at the top of the machine must be clear of any obstructions.
Use only popcorn/butter mixture designed for commercial poppers.
Do not plug machine into an outlet with anything else plugged into it. Do not use extension cords

- Turn all switches to the ON position
- Allow empty kettle to heat 2-3 minutes
- Place oil/butter mixture in kettle. Wait approx 2-3 for it to melt.
- Once it is melted, add the popcorn.
- Close lid on kettle.
- Keep doors open while popping the popcorn
- When corn has popped, rotate the handle to empty the popcorn from the kettle; return kettle to upright position.
- Repeat the cycle, subsequent batches are always more flavorful than the initial batch.
- While popping the final serving of popcorn, as kernels begin to pop, turn the kettle heat off.

WARNING: Do NOT immerse the kettle in water!